Greyline instruments inc.

Data Sheet

SENSOR MOUNTING

Notes:

CLAMP

DO NOT

CLAMP IN THIS AREA

- Use the ¾" NPT "Isolation Coupling" supplied and hand tighten only. Do not clamp sensor body or stem.
- Locate the sensor 1 ft (30 cm) from the sidewall or obstruction for every 10 ft (3 m) depth.
- 3. Do not mount in direct sunlight.

CROSS BAR MOUNT

STANDPIPE LENGTH
AS SHORT AS POSSIBLE
STANDPIPE DIAMETER
AS LARGE AS POSSIBLE
TYPICAL STANDPIPE:
4" / 100 mm DIAMETER

12" / 300 mm LENGTH

NARROW DIAMETER
STANDPIPES (<4" / 100 mm)

OF READING

MAY AFFECT ACCURACY

CONDUIT
ISOLATION
COUPLING
(SUPPLIED)

MUST BE

USED

4. Extend sensor cable up to 500 ft (150 m) with RG62AU coaxial only.

