


# **PZ12 Sensor Specifications & Mounting**



# SPECIFICATIONS:

Maximum Range: 12 ft (3.66 m) 8" (203.2 mm) Minimum Range (deadband): Operating Frequency: 92 KHz

Beam Angle: 8º

Operating Temperature: -40° To 150°F (-40° To 65°C) Temperature Compensation: Automatic, Continuous 20 Psi (1.35 Bar)

Max. Operating Pressure: Sensor Face: **PVC** 

PVC Sensor Body:

3/4" NPT Mounting:

25 Ft. (7.6 M) continuous Cable Length:

RG62AU coaxial

[Optional 50 ft. (15 m) or 100 ft (30 m) continuous] 500 ft. (152 m) RG62AU

Max. Cable Length:

coaxial (splice)

CSA rated Intrinsically Safe Hazardous Rating:

Class I, Groups C,D, Class II, Groups E,F,G with optional Intrinsic Safety Barrier.

# NOTES:

- 1. Shield from direct sunlight (Temp. probe in sensor).
- Use the "Isolation Coupling" supplied for mounting. Do not clamp sensor body or stem.
- Run sensor cable in grounded metal conduit with no other conductors.
- Extend sensor cable with RG62AU coaxial only. Splice with terminal strip connections in recommended Junction Box.
- Refer to the instruction manual for complete installation and wiring information.

### SENSOR POSITION

#### PARSHALL FLUME:

Position the sensor at 2/3 Approach as illustrated. Sensor height must be 8" (203.2 mm) or more above the highest water level.

PALMER BOWLUS & LEOPOLD LAGCO FLUMES: Position the sensor at 1/2 the flume Diameter upstream from the throat of the flume. Sensor height must be 8" (203.2 mm) or more above the highest water level.

#### V-NOTCH & RECTANGULAR WEIRS:

Position the sensor at 3 x maximum Head upstream from the weir plate. Sensor height must be 8" (203.2 mm) or more above the highest water level.

